

## Application Instructions Prespaced Copy

---

1. Clean surface in preparation for placement of legend.
2. Tape the legend into place along top edge. Masking tape may be used.
3. Lift up legend and remove the release liner exposing the adhesive side of copy.
4. Lower legend back into place and burnish with squeegee. On larger copy, work from center outwards.
5. Slowly peel the application tape from the legend at a 180 degree angle.

**NOTE:** On large copy wetting agent can be applied to the copy and mounting surface to aid in application. Squeegee again after 24 hours.

**IMPORTANT:** Clean with water and mild detergent.