

INSTALLATION INSTRUCTIONS CEILING MOUNT (TRACK) – MOUNT I

This mounting is intended for application to a 1" or ½" suspended ceiling track (size to be noted on order). Recommended ceiling height is under 10 feet.


Mounting bracket is made of two pieces of the same part. Two brackets are supplied with each sign. Longer signs require an additional bracket.

1. To mount bracket, snap one half of bracket to track about 4-6" from where end of sign is planned. Place other half of bracket on opposite side of track. The two halves form one unit (see drawing below).
2. Mount second bracket as in step 1.
3. Remove either end cap from sign. Slide sign onto bracket by inserting "T" bottom of bracket into top slot of sign and slide sign into place. Replace end cap.

When mounting longer signs in confined areas (such as corridors) where slide-in method is restricted, insert brackets into sign first and spread bracket to snap over ceiling track. (Some installers prefer this method in open areas as well)

If there are any questions, please contact our Technical Support Department at 800.777.4310.

Typical Application:



IMPORTANT: Prior to installation, remove all contents from box and inspect each sign for damage. Box should contain signs, hardware, and mounting instructions for each style of mount used. Surface of the sign must be handled with care. Clean with water and mild detergent.

Customer is responsible for suitability of each mounting option. Testing is recommended prior to each use.