

Installation Instructions

Wall Mount - Hook & Loop (C-Mount)

Applicable for the following: Arc, FlxSign, Slide (Thin and Standard Profiles), Plaques and PlaquesPlus.


This mount is intended for fabric-covered surfaces. Fabric must have weight and weave qualities to allow the male Hook and Loop Fastener to grip the fabric.

1. Place sign lightly on panel and check position.
2. Apply pressure inward and downward on sign to engage Hook and Loop Fastener in fabric.

Note: This mount is not recommended for signs larger than 144 square inches.

If there are any questions, please contact our Technical Support Department at 800.777.4310.

Typical Applications:



IMPORTANT: Prior to installation, remove all contents from box and inspect each sign for damage. Box should contain signs, hardware, and mounting instructions for each style of mount used. Surface of the sign must be handled with care. Clean with water and mild detergent.

Customer is responsible for suitability of each mounting option. Testing is recommended prior to each use.

Rev. 1.2019